



Please carefully read the below warnings and instructions. Save the instructions for future reference.

- Before installing please contact your local council for semi permanent structure requirements.
- For permanent fixture contact your local council and use appropriate fixings.
- This gazebo is a Semi-Permanent structure. Damage caused by extreme weather conditions including heavy rain or high winds is not covered under warranty.
- Please carefully read all instructions before assembly and use.
- Please separate and identify all parts, ensuring that you have all parts listed.
- To avoid damage to your gazebo, it is recommended that you assemble it on a clean, protected surface.
- Washers must be used when indicated during the assembly process.
- Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.
- As an added precaution we strongly recommend you tighten any loose components after an initial period of use (around 3-6 months). For assured longevity and safe use of your gazebo, we recommend regular checking and tightening of any bolts.

IMPORTANT SAFETY INSTRUCTIONS

- The ground for erecting and anchoring the gazebo is required to be a level, solid and a safe surface.
- Beware of existing utilities underground.
- Keep away from any electrical installations and transportation devices.
- Never climb, sit, or stand on the structure.

| REF | PCE | PIECE | QTY | DIM |
|-----|-----|--|-----|-----|
| | A | Leg tube | 4 | |
| | В | Roof frame | 2 | |
| | B1 | Roof frame | 2 | |
| | B2 | Roof frame | 2 | |
| | B3 | Roof frame | 2 | |
| | с | Roof frame | 2 | |
| | C1 | ······································ | 2 | |
| | D | Roof frame | 1 | |
| | D1 | Roof frame | 1 | |
| | E | Side roof tube | 4 | |
| | F | The middle roof tube | 12 | |
| | G | Supporting frame | 28 | |
| | н | Supporting frame | 2 | |
| | J | Incline stabiliser brace | 8 | |
| | к | Roof edge panel | 2 | |

| REF | PCE | PIECE | QTY | DIM |
|-----|-----|---|-----|-----|
| | L | متعدید میں معلقہ میں معلقہ میں معلقہ م Roof edge panel | 4 | |
| | L1 | Roof edge panel | 2 | |
| | М | Roof edge panel | 14 | |
| | N | Cover plate | 2 | |
| | Р | Angled connection bracket | 2 | |
| | Q | Corner bracket | 4 | |
| | R | Supporting plate | 2 | |
| | R1 | Supporting plate | 2 | |
| | S | Middle cape corner fittings | 12 | |
| | т | Middle bracket | 12 | |
| | U | Corner bracket | 4 | |
| | v | Leg base cover | 4 | |
| | w | Roof panels | 14 | |
| | | | | |
| | | | | |

| [| | | | |
|-----|-----|-------------------------|-----|-----|
| REF | PCE | PIECE | QTY | DIM |
| | AA | M6*15 | 247 | |
| | BB | M6*20 | 14 | |
| | сс | M6*45 | 10 | |
| | DD | M6*39 Bolt | 40 | |
| | EE | Ø7*29 Bolt | 32 | |
| | FF | ST4.2*12 Screw | 16 | |
| | GG | M6 Nut | 34 | |
| | нн | Ø8*Ø28*1.5 Washer | 32 | |
| | JJ | Φ10.5*Φ30*1.5 Washer | 32 | |
| | КК | bolt | 8 | |
| | LL | Allen key | 2 | |
| | MM | Screw driver | 1 | |
| | NN | Spanner Spanner | 1 | |
| | | | | |
| | | | | |

















| R | 2 | ه المع المع | R1 | 2 | L. A. |
|----|---|-------------|----|---|-------|
| AA | 8 | M6*15 | | | |









| STEP 13 | (F) | | × 12 | |
|---------------|-----|---------|------|-------|
| F 12 | A | S 12 | | |
| AA 12 0 M6*15 | EE | 24 | | Ø7*29 |

















Please carefully read the below warnings and instructions. Save the instructions for future reference.

- Before installing please contact your local council for semi permanent structure requirements.
- For permanent fixture contact your local council and use appropriate fixings.
- This gazebo is a Semi-Permanent structure. Damage caused by extreme weather conditions including heavy rain or high winds is not covered under warranty.
- Please carefully read all instructions before assembly and use.
- Please separate and identify all parts, ensuring that you have all parts listed.
- To avoid damage to your gazebo, it is recommended that you assemble it on a clean, protected surface.
- · Washers must be used when indicated during the assembly process.
- Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.
- As an added precaution we strongly recommend you tighten any loose components after an initial period of use (around 3-6 months).
 For assured longevity and safe use of your gazebo, we recommend regular checking and tightening of any bolts.

IMPORTANT SAFETY INSTRUCTIONS

- The ground for erecting and anchoring the gazebo is required to be a level, solid and a safe surface.
- Beware of existing utilities underground.
- Keep away from any electrical installations and transportation devices.
- Never climb, sit, or stand on the structure.