



### 3. Fitting The Handle

- (a) Fit the Handle Shaft to the Handle Grip. Push the split end of the Shaft through the hole at the bottom of the Handle. When pushed through, the split end will expand and lock into place.
- (b) Clip the Handle Cover onto the back of the Handle by pushing the pins into the locating holes. Press in firmly.

### 4. Concrete The Ground Socket

- (a) Mix quick setting cement according to manufacturer's instructions or alternatively mix concrete in the following proportions: 3 gravel:1 sand:1 cement with water. Concrete should be damp enough to hold together when squeezed in the hand.
- (b) Stand the Ground Socket in the centre of the hole and open the Head Section. Check to ensure correct height setting for user and of the Ground Socket to finished surface level. Adjust if necessary. Fold the arms down and fit the Line Retainer for final installation. Ensure the handle is facing the correct way (i.e. towards the path).
- (c) Hold the Rotary upright and fill with another 50mm gravel only. Add concrete mix to approximately half depth. Check to ensure the Mail Column is level, tamp the concrete down using a rod to settle the concrete. Re-check the Main Column level and then fill the hole to within 20mm from the top. Settle the concrete again and re-check the level. Finish with a mix of sand and cement (2 sand:1 cement). LEAVE FOR 48 HOURS BEFORE USING.

## Important Information and Operating Instructions

Remove the Hoist from the Ground Socket several times a year to prevent grit & debris building up and causing the Hoist to seize up in the Socket. Austral's Warranty excludes defects caused as a result of Clothesline Covers or Sunshades.

### 1. Folding The Rotary Hoist

Wind the Head Section down, place your fingers on top of the Bush and squeeze the Cross and Arms up with your hands (Fig.4). Lift the Latch up and gently lower the Cross section to fold Arms down. Tie the Line Retainer around the Arms to ensure lines do not tangle during removal.



Fig. 4

### 2. Removing The Hoist

With Head Section folded and secured, hold the Main Column with both hands, lift and turn the column clockwise to then remove. Fit the Socket Cap onto the Ground Socket.

### 3. Replacing The Hoist

Insert the Rotary Hoist into the Socket and gently lower onto the Pin. Rotate the Main Column until it drops into position. Rotate anti-clockwise for the column to lock into position.

### 4. Unfolding The Head Section

Remove the Line Retainer, grasp the Arms and gently pull them outwards. Raise the Cross up as far as it will go as in Fig.4 and lower the Latch into the locked position. CAUTION: If the Cross will not lift into position, the cords may have tangled. Carefully check the lines. NEVER force the Cross into position.

### 5. Line Tightening

To tighten the lines, open the lever on the Line Tension Lock. Start from the inner position, pulling the cords as you work your way outwards. Pull the Cord Knob tight and lock the lever on the Line Tension Lock back into position.

### 6. During Use

Distribute washing evenly to allow Rotary Hoist to rotate evenly. Wind the Head Section down into the locked position if hanging washing on windy days. Simply pull on one arm to rotate the Head Section while in this position. When finished, wind the line up to allow the Head Section to rotate freely in the breeze.

## State Contact Details

Please contact your local Distributor below for your nearest Stockist of spare parts and accessories.

VICTORIA/TASMANIA	(03) 9799 8122
NEW SOUTH WALES	(02) 9958 1533
STH. AUST./NTH. TERRITORY	(08) 8337 4445
QUEENSLAND	(07) 5596 2520
WESTERN AUSTRALIA	(08) 9455 1985

Please retain the attached Warranty with details of your receipted purchase.

**MANUFACTURER'S WARRANTY**

Austral Clothes Hoists Pty Ltd ("Austral") provides the following warranty in relation to its Clothes Lines products ("Product").

**WARRANTY**

Subject to the exclusions below, Austral warrants:

- **for 12 months from date of purchase:** the repair or replacement, in its discretion, of any Product that fails to operate correctly due to faulty workmanship or defective materials. The "materials" includes the plastic components and cord.
- **for 20 years from date of purchase:** the repair or replacement, in its discretion, of any part of the tubular frame that is broken or distorted as a direct result of rust. The "tubular frame" comprises the circular, square or rectangular hollow steel frame on powder coated or galvanised Product.

The benefits of this warranty are in addition to the non-excludable rights and remedies imposed by Australian State and Federal legislation.

**WARRANTY CLAIMS**

To make a warranty claim, please contact your place of purchase or your local Distributor with details of the alleged defect and your original receipt as proof of purchase. Where it is deemed necessary, Austral will arrange for the inspection of your Product.

You must bear the cost of making the Warranty claim. Austral will bear the cost of repairing or replacing defective Product (including freight or postage of replacement Product).

**WARRANTY EXCLUSIONS**

Austral's Products are suitable for air drying purposes.

The Warranty does not cover:

- defects caused through abuse or misuse.
- incorrect adjustments or unauthorised repairs.
- defects caused by incorrect installation.
- Product damage or deterioration due to abnormal environmental conditions including storm damage, fire, wind, humidity, pressure, stress and similar.
- powder coat deterioration caused by exposure to sea air where the Product is installed in coastal areas.
- defects caused through normal wear and tear.
- defects caused through the installation or use of a clothesline cover or sunshade.

**SPARE PARTS**

Austral maintains stock of spare parts for a reasonable period of time. Spare parts may not be available for the entire duration of this Warranty.

Austral reserves the right to repair or replace defective Product with parts and components of similar quality, grade and composition where an identical part or component is not available.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired.

**LIMITATIONS**

Austral makes no express warranties or representations other than as set out in this warranty. The repair or replacement of the Product or part of the Product is the absolute limit of Austral's liability under this express warranty.

**Distributor Contacts:**

State:	Phone:	Address:
VIC & TAS	03 9799 8122	32-34 Hydrive Close, Dandenong South, VIC, 3175
NSW & ACT	0428 262 471	PO Box 380, Cammeray, NSW, 2062
SA & NT	08 8337 4445	20 Sunbeam Road, Glynde, SA, 5070
WA	08 9455 1985	Unit 3, 12-14 Panama Street, Canning Vale, WA, 6155
QLD	07 5596 2520	8 / 24 Palings Court, Nerang, QLD, 4217

Contact your local Retailer or Distributor for Spare Parts, Accessories and Warranty claims.

*Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.*