WARRANTY

GERNI Warranty Process

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
GERNI – 1-23 Letcon Drive, Bangholme, Victoria, Australia 3175 provides the following warranty in relation to your Gerni Pressure Washer machine.

DOMESTIC WARRANTY

Definition; A machine purchased for domestic household use.

Gerni warrants that, subject to the exclusions and limitations below, the product will be free from defects in the materials and workmanship for the duration of the warranty period from the date of purchase.

2 YEAR STANDARD WARRANTY

Machines & accessories included are as follows: Gerni 3000*, 3300*, 3600*, 5000*, 9000
*Subject to an additional 3 year extended warranty with online registration at www.gerni.com.au

5 YEAR STANDARD WARRANTY

Machines included are as follows: Gerni 5300*, 7000*, 7300*
*Subject to an additional 2 year extended warranty with online registration at www.gerni.com.au

2 YEAR STANDARD WARRANTY

All Gerni accessories are subject to a 2 year standard warranty, to qualify for an exchange of your product you must have proof of purchase*.
*Extended warranty is not applicable to Gerni accessories, only pressure washer machines.

GERNI Warranty Claims

Equipment defects covered by the warranty will be repaired or replaced by one of our Authorised agents within the Gerni organisation. Find your local service agent here: www.gerni.com.au

- If a fault occurs, the user must first take their pressure washer machine to the closest Gerni Authorised Agent or place of purchase to be diagnosed for fault. It is important that you have the pressure washer serial number accompanied with your proof of purchase receipt and a copy of your Gerni online-registration certificate to ensure your pressure washer is covered under warranty.
- If a fault is diagnosed and your machines is inside stated warranty period, then your machine will be repaired or replaced at no cost. If your machine is diagnosed faulty but your machine has fallen outside the stated warranty period, the cost of diagnosis or repair will be covered by the user.

Exclusions:

- The product has been modified, repaired, or serviced by someone other than a Gerni authorised service centre.
- The product has been used other than for the purpose to which it is designed.
- The product has been exposed to user abuse such as knocks, bumps and extreme temperatures conditions.


Gerni 1-23 LETCON DRIVE, BANGHOLME, VICTORIA, AUSTRALIA 3175.

1020

Gerni 3000
HIGH PRESSURE WASHER

SPECIFICATIONS

VOLTAGE:	220-240V~50-60Hz
POWER:	1400W
MAX. PRESSURE:	11.5 MPa (1670psi)
RATED PRESSURE:	8.5 MPa (1232psi)
MAX. INLET PRESSURE:	1 MPa (145 psi)
RATED FLOW:	5.2L/min
MAX. FLOW RATE:	7.3L/min
HOSE LENGTH:	5m
MAX. WATER INLET TEMP.:	40°C
IP RATING:	IPX5
WEIGHT:	6.2kg



5 YEAR WARRANTY
2 Year Standard
+3 Year Online Extension

Gerni 1-23 LETCON DRIVE, BANGHOLME, VICTORIA, AUSTRALIA 3175. GPW-3000

SAFETY

HIGH PRESSURE WASHER SAFETY

WARNING! The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Young children should be supervised to ensure that they do not play with the appliance.

WARNING! High pressure injection injuries are considered to be medical emergencies. In the event of a high pressure injection injury occurring, seek medical advice immediately.

WARNING! It is prohibited to use Pressure Washers on materials containing asbestos (Cement sheet roofs, Fences, Walls etc.). Large numbers of asbestos fibres may be released into the air, posing a serious health hazard. If unsure about the materials you are spraying, it is recommended that you contact your local council or government authority.

- Before connecting a tool to a power source (mains switch power point receptacle, outlet, etc.) be sure that the voltage supply is the same as that specified on the nameplate of the tool. A power source with a voltage greater than that specified for the tool can result in serious injury to the user, as well as damage to the tool. If in doubt, do not plug in the tool. Using a power source with a voltage less than the nameplate rating is harmful to the motor.
- Unsafe operation of your high pressure cleaner could lead to serious injury or death to you or others.
- The spray gun/wand is a powerful cleaning tool that could look like a toy to a child.
- Improper control of gun/wand can result in injuries to self, others and property damage. Reactive force from the spray can result in gun/lance movement, potentially causing the operator to slip, fall or misdirect the spray.
- Become familiar with the operation and controls of the pressure cleaner.
- Keep children away from the pressure cleaner at all times.
- Never modify or remove the safety features of this product.
- Do not operate the machine with missing, broken or unauthorized parts.
- Never leave wand unattended while unit is running.
- Keep work area free of obstacles.
- Stand on stable surface and grip gun/lance firmly. Expect the gun to kick back when engaged
- Do not use to pump flammable or explosive liquids such as gasoline, fuel oil, kerosene,solvents or thinners. Pump should only be used with liquids compatible with pressure washer component materials. Failure to follow to this warning can result in serious personal injury, death and/or property damage.
- Only use cleaning agents designe
may adversely affect the safety an
- Do not use the appliance within ra
- High pressure jets can be danger
animals, live electrical equipment
- Do not direct the jet against yours
- To ensure appliance safety, use o
manufacturer.
- High pressure hoses, fittings and
fittings and couplings recommend
- Do not use the appliance if a supp
devices, high pressure hoses, trig
- Water that has flowed through a b
- Depending on the application, shi
the emission of hydrous aerosols
device. If shielded nozzles are not
class FFP 2 or equivalent may be
- The electric supply connection sh
is recommended that the electric
that will interrupt the supply if the
prove the earth circuit.
- Never touch the mains plug or po
- Always disconnect the product fro
- This product must not be connect
local and national plumbing regula
- Do not operate the machine at ter
- If an extension cord is used, it sha
and off the ground. It is recomme
the socket at least 60 mm above
- It is recommended that a reinforce
connection.
- During use of high pressure clean
to health.

ELECTRICAL SAFETY

WARNING! When using mains-powered tools, basic safety precautions, including the following, should always be followed to reduce risk of fire, electric shock, personal injury and material damage.
Read the whole manual carefully and make sure you know how to switch the tool off in an emergency, before operating the tool.
Save these instructions and other documents supplied with this tool for future reference.
The electrical motor has been designed for 230V and 240V only. Always check that the power supply corresponds to the voltage on the rating plate.
Note: The supply of 230V and 240V on Gerni tools are interchangeable for Australia and New Zealand.

This tools is double insulated; therefore no earth wire is required.
Note: Double insulation does not take the place of normal safety precautions when operating this tool. The insulation system is for added protection against injury resulting from a possible electrical insulation failure within the tool.

If the supply cord is damaged, it must
a hazard.

Using an Extension Lead
Always use an approved extension lea
extension lead for signs of damage, w
When using an extension lead on a re
suitable for the power input of the too
electric shock.

Residual Current Device (RCD)
The pressure washer must be protecte
current device reduces the chance of


GENERAL POWER TOOL SAFETY


WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.
Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.


1. Work area safety
   - **a. Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
   - **b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
   - **c. Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.
2. Electrical safety
   - **a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
   - **b. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
   - **c. Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
   - **d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
   - **e. When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
3. Personal safety
   - **a. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
   - **b.Use personal protective equipment. Always wear eye protection.** Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
   - **c. Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
   - **d. Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
   - **e. Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
   - **f. Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
   - **g. If devices are provided for the c**
   - **these are connected and prope**
   - **h. Do not let familiarity gained fro**
   - **ignore tool safety principles.** A
4. Power tool use and care
   - **a. Do not force the power tool. Us**
   - tool will do the job better and safer
   - **b. Do not use the power tool if the**
   - controlled with the switch is dangel
   - **c. Disconnect the plug from the po**
   - **making any adjustments, chang**
   - measures reduce the risk of startin
   - **d. Store idle power tools out of th**
   - **the power tool or these instruct**
   - hands of untrained users.
   - **e. Maintain power tools.** Check for
   - other condition that may affect the
   - use. Many accidents are caused by
   - **f. Keep cutting tools sharp and cl**
   - likely to bind and are easier to contr
   - **g. Use the power tool, accessories**
   - **into account the working condi**
   - operations different from those inte
   - **h. Keep handles and grasping sur**
   - and grasping surfaces do not allow
5. Service
   - **a. Have your power tool serviced b**
   - **parts.** This will ensure that the saf


ASSEMBLY


COMPONENTS


















A TRANSPORT HANDLE







B WHEEL ASSEMBLY









C ATTACH INLET COUPLING







D SETUP HIGH PRESSURE HOSE










E ASSEMBLE SPRAY GUN











F FIT AN ACCESSORY

COMPACT JET SPRAY NOZZLE




- For removing ingrained dirt.
- High impact rotating jet spray.
- Covers a large area.

FIXED FAN NOZZLE



- 15° Fixed fan spray.
- Everyday general cleaning.

CLASSIC PATIO GACC-CP




- For cleaning horizontal surfaces.
- Suitable for brick, cement & wood.


USAGE

CONNECT TO TAP


WARNING! High pressure jets can be dangerous if not used properly. Do not direct the jet at persons, animals, live electrical equipment or the pressure washer itself.




1 Run water through hose.




2 Turn off tap.



3 Connect water hose.




4 Power & water.




5 Unlock Spray Gun.




6 Purge pressure.



7 Release trigger.



8 Switch on (I).



9 Start cleaning.




TAKE A BREAK


WARNING! High pressure jets can be dangerous if not used properly. Do not direct the jet at persons, animals, live electrical equipment or the pressure washer itself.

WARNING! Perform the procedure below if taking a break for more than 5 minutes. Failure to do so may damage the pump or cause the equipment to overheat and malfunction.


1 Lock trigger.




2 Switch off (0).



3 Switch off & unplug.



4 Turn off tap.




NOT WORKING?

SYMPTOM	POSSIBLE CAUSE	RECOMMENDED ACTION
Fluctuating Pressure	Pump is drawing in air	Check that hoses and connections are airtight
	Insufficient water supply	Increase water supply at the tap, check for blockages or kinks in the hose and/or swap to a larger diameter hose
	Accessory nozzle dirty or blocked	Clean accessory nozzle bore as there may be a blockage from dirt or debris please use cleaning needle provided
The machine stops mid-use	Incorrect mains voltage	Check that the mains voltage corresponds to the specification on the model tag
	Thermal sensor activated	Leave pressure washer for 5 minutes to cool down
	Nozzle partially blocked	Please refer to Care & Cleaning (step 5) section of the user manual
Machine Pulsating/ inconsistent spray	Air in the inlet hose/pump	Press & hold the spray gun trigger and allow the machine to run until normal working pressure resumes
	Kinked water hose	Unwind the water hose fully
	Insufficient water supply	Increase water supply at the tap, check for blockages or kinks in the hose and/or swap to a larger diameter hose.
No water emitted	Water filter blocked	Clean the inlet filter
	Blocked nozzle	Use cleaning needle to clean outlet
Machine often starts and stops by itself	Spray gun may be leaking due to worn/damaged O-ring	Please contact your closest Gerni Authorised Repair Agent www.gerni.com.au


MAINTENANCE

STORAGE


1 Turn off tap.




2 Switch off (0).




3 Drain water from Spray Gun.




4 Remove water hose.




5 Disconnect Spray Gun.




6 Switch on (I).




7 Drain High Pressure Hose.




8 Switch off (0).




9 Disconnect High Pressure Hose



10 Switch off & unplug.




11 Dry parts before storage.




CARE & CLEANING

WARNING! Ensure the tool is turned off and disconnected from the power supply before performing any of the following operations.


1 Switch off (0).




2 Switch off & unplug.




3 Disassemble accessories.




4 Rinse accessories.



5 Clean Nozzles.




6 Remove Water Inlet Coupling & Filter.




7 Rinse Inlet Filter.



INSPECT, REPLACE IF DAMAGED



8 Dry parts before storage.



DEFINITIONS

	Read instruction manual
	Double insulated
	Regulatory compliance mark
	Warning!
	Wear eye protection
	Wear gloves
	Not suitable for connection to potable water mains
	Warning! High pressure jets can be dangerous if not used properly. Do not direct the jet at persons, animals, live electrical equipment or the pressure washer itself
V	Volts
Hz	Hertz
~	Alternating Current
W	Watts
L/min	Litres per minute
psi	Pounds per square inch
Mpa	Mega Pascals
IPX5	Ingress protection from water

DISPOSAL ADVICE

POWER TOOL
Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.

PACKAGING
Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

NEED HELP?

www.gerni.com.au

customerservice@gerni.com.au

AUS 1300 162 689
NZ 0800 700 124