

GRIPSET
Betta

Easier, Safer, Betta!

**FAST DRY,
TILE AFTER
4 HOURS**

INSTRUCTION FOR USE

Gripset Betta Waterproofing System is made up of 3 steps;

Priming, Detailing & Membrane.

☒ **STEP 1: PREPARATION/PRIMING**

Surface must be prepared thoroughly before commencing.
Surfaces are to be sound, dry and clean.

Apply suitable primer to the surface. *Gripset Betta have a range of primers suitable to cover all solutions.*

☒ **STEP 2: INBEDDING THE DETAILING IN CORNERS AND JOINTS**

Apply a coat of Betta Under Tile Membrane around the corners and joints of the surface, then lay the detailing over top. Using another coat of Under Tile Membrane to embed the detailing into the surface (ensuring no bubbles and detailing is flush with the surface).

☒ **STEP 3: APPLY BETTA UNDER TILE MEMBRANE GENEROUSLY TO THE ENTIRE SURFACE**

A minimum of 2 coats is to be applied at a total minimum coverage of 1.5 Litre/m², forming a dried film thickness of approx 1.2mm.
Apply subsequent coats at different directions to the previous coat.

Allow 1 hour between coats and 4 hours before tiling.

Please note: to be used as a guide only, Gripset Betta recommend reading the label of each product prior to any use of the products.

EQUIPMENT REQUIRED:

☐ **Membrane:**
Gripset Betta
- Under Tile
Membrane



☐ **Primer:**
Gripset Betta
- Prep Coat
Primer



☐ **Detailing:**
Elastic Joint
Band



☐ **Applicator:**
Brush Applicator



☐ **Clean Up:**
Waterbased Turps



**AUS 1800 810 123
NZ 0800 474 7738**

  
www.gripsetbetta.com



P/N 95169