

Install instructions:


Step 1: Draw a line down the centre of the door edge.



Step 2: Mark the height of your latch - allowing for any specification from the door manufacturer.




Step 3:
Install the Latch hole plate on the centre line, using the screw supplied with your door handles.
Install plate Flat side against door - to suit handles with 70mm backset.
Install plate raised side against door - to suit handles with 60mm backset.




Step 4: Install the handle hole jig onto the face of the door, by sliding it into the Latch plate.
Note: Do not use the fixing holes to hold this in, these are used if additional holding is required, they will mark the face of your door.



Step 5: Drill out the Handle Hole using the 54mm holesaw.
Tips: Drill until tip of centre drill comes through the otherside and then finish off hole by drill from the other side for a perfect finish.




Step 6: Drill out the latch hole by using the 25mm Holesaw.




Step 7: Remove the Hole jig and Latch jig.


Step 8: Attached the latch routing plate to the latch side of the door by gently taping with a hammer, lining up with the screw holes of the Latch hole plate.



Step 9: Attach the routing bit and using your drill route out the template.



Step 10: Remove routing plate and clean up area with a Chisel.



Door handle should now be ready to install.
Door handle not included.
Note:
Suitable for all doors with 60mm & 70mm backsets.

