

## INSET BATHTUB

### IMPORTANT

- Local or state regulations may require some work to be performed by a licensed tradesperson. Check these regulations before attempting any DIY work.
- Prior to installation, completely remove the protective film and thoroughly inspect the entire bath for damage or defects. Damage or defects found after installation are not covered by warranty.

### INSTALLATION NOTES

- The bath must be level on all top edges.
- The rim and base of the bath must be fully supported.
- If timber supports are used to support the base, ensure that a generous amount of silicone is applied.

