

AQUA PROTECT TECHNOLOGY:

Creates a highly durable barrier that repels water and resists mould, dirt and stains.

UV PROTECTION:

Blocks out harmful UV rays for longer lasting results.

ABRASION RESISTANCE:

Designed to withstand the rigours and abrasion of opening and closing doors, windows and gates.

WATER BASED:

Low odour, fast drying, easy clean up.

FINISH:

Semi-transparent, designed to penetrate the timber and provide long lasting protection against natural elements.

IDEAL FOR:

Hardwood and softwood exterior timber cladding, windows, doors, bi-folds, gates & pergolas.

SUITABLE SURFACES:

New and weathered exterior hard & soft timber species, such as Western Red Cedar window and door joinery. (Not suitable for decks).

FINISH:

Semi-transparent, low lustre.

COVERAGE:

Approx. 12m² per litre (dependent on porosity of the timber substrate).

SAFETY & FIRST AID

KEEP OUT OF REACH OF CHILDREN. Avoid skin and eye contact.

IF SWALLOWED: Give plenty of water to drink. Seek medical advice.

EYE CONTACT: Rinse with plenty of running water. Seek medical advice if irritation occurs.

24 HOUR MEDICAL EMERGENCY RESPONSE SERVICE CALL:

AUSTRALIA: 1800 883 254

NEW ZEALAND: 0800 000 096



SURFACE PREPARATION

NEW HARDWOOD TIMBER:

Allow the timber to naturally weather for 6 weeks. During this period, wet timber with a garden hose as regularly as possible. This will flush the natural timber tannins from the timber substrate and reduce the risk of timber tannin residue appearing once exterior oil has been applied. Alternatively, apply Johnstone's Professional Tannin & Oil Remover followed by Johnstone's Professional Deck & Timber Cleaner following label instructions. Allow to completely dry. Lightly sand timber surface. This will raise the fibres of the timber grain and provide a greater key for the Johnstone's Professional Timber Oil to adhere to.

SOFTWOODS (INCLUDING TREATED PINE AND WESTERN RED CEDAR):

Ensure timber surface is dry, clean and free from dirt and debris prior to application.

PREVIOUSLY PAINTED OR VARNISHED TIMBER:

Remove previously coated material back to bare timber using Johnstone's Professional Timber Stripper. (Timber surface may still have to be sanded once stripper has been used). Clean timber with Johnstone's Professional Deck & Timber Cleaner following label instructions to remove any contaminants such as mould or tannin bleed residue. Allow to completely dry prior to coating.

PREVIOUSLY STAINED AND OILED TIMBER:

Clean timber with Johnstone's Professional Deck & Timber Cleaner, rinse off timber substrate following label instructions and allow to completely dry. Lightly sand the timber surface to improve adhesion. Ensure timber is free from dirt, dust and contaminants prior to the application of Johnstone's Professional Timber Oil.

WEATHERED AND GREY TIMBER:

For best results, clean timber with Johnstone's Professional Deck & Timber Cleaner following label instructions. Use a high pressure washer to remove residue and allow to completely dry. Additional light sand may be required to remove any grey areas not removed by Johnstone's Professional Deck & Timber Cleaner. Ensure surface is dirt and dust free prior to the application of Johnstone's Professional Timber Oil.

TOUCH DRY:

30 minutes

RECOAT:

Allow a minimum of 1 hour between coats

APPLICATION

1. Stir thoroughly with a broad flat paddle before and during use.
2. Apply liberally along the length of the timber boards including exposed edges and end grain preferably by brush or applicator pad. Initially applied, the Johnstone's Professional Timber Oil will look slightly opaque however, will dry to a semi-transparent finish allowing the timber grain to remain visible.
3. Apply two coats allowing 1 hour between the first and second coat. For increased durability, longevity and coverage of the 12 month Aqua Protect guarantee* a third coat should be applied.

MAINTENANCE:

Re-apply as the timber changes colour and presents a dull appearance or when water repellency diminishes due to weathering. Follow surface preparation instructions prior to applying a maintenance coat of Johnstone's Professional Timber Oil.

DRYING AND RECOAT TIME:

All timings quoted at 25°C and 50% humidity. Cooler or humid conditions may require longer.

IMPORTANT:

Do not apply this product in temperatures below 10°C or above 35°C or when heavy rain or dew is expected during the drying period. In hot temperatures, do not apply in direct sunlight. Attempt to coat when project is shaded.

CLEAN UP:

Clean brushes and equipment with water.

COVERAGE:

Approx. 12m² per litre.

PROTECT OUR ENVIRONMENT

Do not pour left over product down the drain. Unwanted product should be brushed out on newspaper allowed to dry then disposed of via domestic waste collections. Empty containers should be left open in a well ventilated area to dry out. When dry, recycle the container via steel can recycling programs. Disposal of empty containers via domestic recycling programs may differ between local authorities. Check with your local council first. For responsible disposal of product and packaging visit paintback.com.au (Australia only).