

EZY-LITE 300 & 400 ROUND SKYLIGHTS INSTALLATION GUIDE

INSTALLATION INSTRUCTIONS – TILE ROOF

- Remove several tiles from above the site for your new skylight
- Use a sharp object to mark the centre of the spot where you wish to install the ceiling ring.
- Slip flexi duct over metal collar under skylight dome and fix in place using aluminium tape provided.
- Fit assembly to tiles by sliding tray under tile at top and over tiles at sides and bottom.
- Use a hammer to carefully shape base to tile profile.
- Use silicone to seal under the edges of the tray to the tiles.
- Use the ceiling ring as a template and cut out the plaster.
- Trim off excess flexi duct before fitting ring to ceiling with screws and tabs provided
- Attach shaft to ring with aluminium tape.
- Gently bend the diffuser panel to allow access through ceiling ring.
- Install white plugs provided into the end of the screws to finish off. – Now you are able to enjoy your skylight.

TOOLS REQUIRED: Tape Measure, tin snips, cordless drill with start driver bit, hammer, plaster or jigsaw, small angle grinder with stone wheel, silicone gun and silicone.

EZY-LITE 300 & 400 ROUND SKYLIGHTS INSTALLATION GUIDE

INSTALLATION INSTRUCTIONS – CORRUGATED ROOF

- From inside the roof use a sharp object to mark the centre of the spot where you wish to install the ceiling ring, also use a drill to mark the roof to indicate the site for installation.
- Cut out the roofing 10mm larger than the flexi duct size.
- Slip flexi duct over metal collar under skylight dome and fix in place using aluminium tape provided.
- Drop ducting through opening and sit base on roof.
- Use a hammer to gently form the edges of the tray to match the roof profile.
- Use silicone to seal under the edges of the tray to the metal roof.
- Use the ceiling ring as a template and cut out the plaster
- Trim off excess flexi duct before fitting ring to ceiling with screws and tabs provided
- Attach shaft to ring with aluminium tape.
- Gently bend the diffuser panel to allow access through ceiling ring.
- Install white plugs provided into the end of the screws to finish off. – now you are able to enjoy your skylight.

TOOLS REQUIRED: Tape Measure, tin snips, cordless drill with start driver bit, hammer, plaster or jigsaw, silicone gun and silicone.