

Holger Kitchen Cart 799x349


Holger Chariot de cuisine 799x349

Holger Carro de cocina 799x349

Holger Köksvagn 799x349


Holger Küchenwagen 799x349

INTERBUILD® REAL WOOD




Component List

- Before assembly please check carefully if the package contains all of components on the list.
- Avant de procéder à l'assemblage, veuillez vérifier si le contenu de l'emballage contient toutes les composantes inscrites sur la liste.
- Antes del montaje, compruebe cuidadosamente si el paquete contiene todos los componentes de la lista.
- Innan montering kontrolleras noggrant om paketet innehåller alla komponenter på listan.
- Bitte prüfen Sie vor dem Zusammenbau sorgfältig, ob das Paket alle auf der Liste aufgeführten Komponenten enthält.



- Please tighten the screws at regular intervals.
- Veuillez serrer les vis à intervalles réguliers.
- Por favor, apriete los tornillos a intervalos regulares.
- Dra åt skruvarna med jämna mellanrum.
- Bitte ziehen Sie die Schrauben in regelmäßigen Abständen an.

1.



Holger Kitchen Cart 799x349

Holger Chariot de cuisine 799x349


Holger Carro de cocina 799x349

Holger Köksvagn 799x349


Holger Küchenwagen 799x349

INTERBUILD® REAL WOOD

2.



3.



Holger Kitchen Cart 799x349

Holger Chariot de cuisine 799x349


Holger Carro de cocina 799x349

Holger Köksvagn 799x349

Holger Küchenwagen 799x349

INTERBUILD® REAL WOOD

4.



5.

