


# WAXSTIX®

Timbermate®  
group

## Waxstix®

### Wax Touch-Up Crayons

Fix imperfections instantly



### Colours to suit almost any timber

Waxstix are so easy to use and so handy for quick repairs to scratched or damaged timber, their #1 Feature is it can be coated and stained. Also as Waxstix contain no beeswax they will not leave any white ring marking otherwise known as the "halo effect".


For most small scratches, simply rub the stick over the damaged area. For larger, deeper indentations (where Timbermate Water-based Woodfiller cannot be used), heat a knife blade with a flame or a soldering iron or stove lighter and fill damaged area with hot wax. Remove excess wax by rubbing with the smooth side of sandpaper, a piece of cardboard or old credit card. Use a cotton cloth to buff and remove excess wax.




### Fix imperfections instantly



Nail holes



Timber joins



Scratches

### Waxstix colours

Colours shown are a guide only



Baltic Pine



Cedar



Ebony



Mahogany



Maple



Jarrah



Pine



Rosewood



Tas Oak



Teak



Walnut



White

Also available in natural which is a clear wax. Perfect for indentations where there is no surface "scratch".

# Product code & barcode numbers

Product Code	Size	Barcode
WB1	Baltic Pine	9315284510000
WC1	Cedar	9315284510017
WE1	Ebony	9315284510123
WM1	Mahogany	9315284510024
WMA1	Maple	9315284510031
WJ1	Jarrah	9315284510109
WN1	Natural	9315284510130
WP1	Pine	9315284510048
WR1	Rosewood	9315284510055
WO1	Tas Ok	9315284510062
WT1	Teak	9315284510079
WW1	Walnut	9315284510086
WWH1	White	9315284510093

