



Floating Shelf Installation Instructions

Hardware Supplied
















Please note: For safety, the bracket pipes are angled slightly upward to prevent shelf droop when shelf is loaded to capacity.