














RESIN WICKER EGG CHAIR

Assembly Instructions

Item number:0260220


A		1
B		1
C		2
D		2
E		12
F		3
G		3
H		3
I		3
J		1
K		1
L		1

①




Attach the chair legs (C&D) to the chair base (B), using bolts (E). When all bolts are in position, tighten securely using Allen Key (J).

②




Attach the roof (A) to the seat base (B), using bolts(F), washers (G) and nuts (H). When all bolts are in position, tighten securely with Allen Key (J) and spanner (K). Cover the nuts with the nut covers (I).

③



④



Place the chair right side up and insert the seat cushion (L). Your egg chair is now ready for use.