





**THIS PRODUCT SHOULD BE PERMANENTLY ANCHORED TO THE WALL OR OTHER SUITABLE SURFACE
TO AVOID SERIOUS INJURY OR DEATH.**

This product should be permanently anchored to the wall or other suitable surface to avoid serious injury or death. To help avoid any serious injury or death, this product includes a fixing bracket to prevent toppling. we strongly recommend that this product be permanently fixed to the wall or other suitable surface. Fixing hardware is not included since different surface materials require different attachments. please seek professional advice if you are in doubt what fixing hardware to use. Regularly check your fixing device.






Parts List



A x12pcs



B x12pcs




C x20pcs




D x8pcs



E x16pcs



F x4pcs




G x14pcs



H x14pcs



I x12pcs



J x1pc



K x1pc




L x1pc




M x1pc


Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 8




Step 9



Step 10



Step 11



Step 12

