

ASSEMBLY INSTRUCTIONS

BAYFIELD STEEL WICKER BAR TABLE

Item No. 0177371

PART LIST

Table Top



A x1

Right Leg



B x2

Left Leg



C x2

Cross Support Bar



D x2

Center Support Bar



E x1

Glass



F x1

Cap, Screw and Washer



G x24


Allen Key



H x 1


ASSEMBLY INSTRUCTIONS

WICKER BAR TABLE



Step 1

Turn over the table top frame on to a clean protected surface. Use screws and washers (G) to fit the legs (B) and (C) to the table top (A). Loosely tighten screws using allen key (H). Then attach the cross support bar (D) to the table legs (C & B), using screws and washers (G) and allen key (H). When all screws are in position tighten securely using the Allen Key (H). Add the screw caps to each screw head.



Step 2

Carefully turn over your table and attach the center support bar (E) to the cross support bar (D), using screws and washers (G) and allen key (H). Once all screws are in position, tighten securely, then cap the screws. Carefully place the glass table top into the bar table. Your setting is now ready for use.