37.5x21.5cm


INSTRUCTION FOR BACK PACK GARDEN SPRAYER



INSTRUCTION MANUAL

DO NOT OVERPRESSURISE

Instructions for Use




 Select the right nozzle for either jet or fan spray.

to boost pressure.


- For continuous spraying,
 Press the small rounded tab at the top of the trigger mechanism into lock position.
- Clean and dry the sprayer after use and store in a dry place.

Sprayer Assembly

Screw on the trigger mechanism onto the wand and tighten(see fig A). Then screw the other end of the trigger mechanism to the hose connector





2.Connect the nozzle to the wand and tighten.




3.Connect the pump handle to one of the pump connectors at the base of sprayer (there is a left and right connector).Pump the handle to apply pressure.


Fixing Shoulder Strap






- Remove the small plastic clip from the 3. Fix the hook at the other end of the strap shoulder strap and thread the belt loop to the wire base of the sprayer.
 through the hole at the top of the sprayer.
- Replace the clip through the loop, clamping the belt as well.





- 4. Slide the shoulder pads into a comfortable 6. Adjust strap length to the desired fit.
- Repeat for the second strap.

INSTRUCTION FOR BACK PACK GARDEN SPRAYER



| 01 Nozzle assembly | 35 Rocker arm(connecting rod) |
|--------------------------------------|-------------------------------|
| 02 O-ring © | 41 Pad |
| 03 O-ring ① | 42 Bush |
| 04 Lance | 43 Clamp ring |
| 07 Seal insert | 44 Screw |
| 08 Nut of hose connector | 45 Nut |
| 09 Hose | 46 Screw |
| 12 Washer 🖹 | 47 Nut |
| 14 Trigger | 48 Cover |
| 23 Air filter | 51 Hard pump bar sleeve |
| 24 Sealing washer | 52 Hard pump rod |
| 25 Valve slice | 53 Hard pump arm |
| 26 O-ring | 54 Socket head screw |
| 27 O-ring | 55 Split pin |
| 28 Cylinder | 71 Cap |
| 29 Stainless pad | 71-1 Seal for air hole |
| 30 Tapping screw | 71-2 Seal |
| 31 Leather cup assembly (Viton seal) | 72 Filter sleeve |
| 32 Piston | 73 Strap clamp |
| 33 Clamp | 74 Shoulder pad |
| 34 Clamp | 75 Strap |
| | 76 Strap hook |
| | 77 Bottle sprayer |

INSTRUCTION FOR BACK PACK GARDEN SPRAYER



SAFETY INSTRUCTIONS

CAUTION: CONTENTS UNDER PRESSURE. READ THIS BEFORE OPERATING.

- Always wear protective clothing, gloves and mask when spraying. Suitable measures must be taken to keep the unit out of the reach of children.
- If spraying in light wind conditions, always spray with the wind blowing the spray away from you.
- Do not spray contents of sprayer on persons or animals.
- Ensure all parts are intact and the temperature of the liquid under 40℃ before each use.
- Chemical sprays are dangerous if swallowed or come in contact with the skin, always refer to the chemical supplier safety instructions or contact the poisons information centre or doctor immediately.
- Always release pressure before refiling, servicing or storing.
- Do not leave sprayer (filled, empty or pressurized) unattended in direct sunlight.
- After each use ensure all remaining liquid is emptied from the backpack sprayer and washed out with water before storing away.
- Not to be used to spray solvents or flammable liquids.











OTECTIVE EYE
LOTHING PROTECTION

YE WEAR ECTION GLOVES

A.S APPROVI

CARE AND MAINTENANCE

- Safety Valve and trigger test: fill the bottle completely with clean water. Pressurize by pumping a few times. The air should vent through the valve. Then press down lever with thumb pressure to operate, if there is leakage, service of replace the O ring.
- •Strain thick mixtures before each use to reduce the chance of blockage.
- Due to product testing requirements, this sprayer may contain a small amount of water residue.

GUARANTEE Under Australian and New Zealand laws, we guarantee this product is acceptable quality and fit for purpose.


INSTRUCTION FOR BACK PACK GARDEN SPRAYER



TROUBLE SHOOTING

| PROBLEM | SOLUTION |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The sprayer is leaking | identify the area of the leak and check rubber seals (refer to product diagram for seal locations – part numbers 2,3,12,24,27,31). Check that they are properly fitted. Replace any damaged seals. |
| The pump is difficult to use | check the air chamber filter and clean it if any blockage check the two valve slice (25) at the top and bottom of the pump and clean them if any blockage. Refer Fig.1 |
| The sprayer can not hold the pressure | check valve slice (25) at the top of the pump and clean it if any blockage. check o-ring (26) and change if it is broken or deformed. |
| The sprayer can not spray | inspect the filter and nozzle assembly (01) and clean them if any blockage. Refer Fig.2 |





SPARE PARTS LIST AND DETAILS

