















Quick Start Guide







RBC254SESO / RPP254JO / RLT254CDSO / RLT254SDSO

WARNING: This Quick Start Guide is not a substitute for reading the operator's manual. To reduce the risk of injury, the user must read and understand the operator's manual before using the product.


TO START A COLD ENGINE:

- 1  50:1 ratio = Mix 20 mL of synthetic 2-stroke oil per litre of petrol. Ensure that the fuel is fresh and is correctly mixed before pouring it into the fuel tank.
- 2  Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- 3  Set the choke lever to the full choke position.
- 4  Hold down the throttle lock, and squeeze the throttle trigger.
- 5  Using manual operation:
Pull the starter grip and rope up to 4 times or until the engine starts.
or
 Using the ONE+ EASYSTART module:
Set the ONE+ EASYSTART module to , insert the module into the starter housing, and press the ONE+ EASYSTART power button for up to 4 seconds or until the engine starts.
- 6  Set the choke lever to the half choke position.
- 7  Using manual operation:
Pull the starter grip and rope up to 6 times or until the engine starts.
or
 Using the ONE+ EASYSTART module:
Set the ONE+ EASYSTART module to , insert the module into the starter housing, and press the ONE+ EASYSTART power button for up to 4 seconds or until the engine starts.
NOTE: If the engine does not start, repeat the procedure from step 3 until the engine starts.
- 8  Allow the engine to warm for 10 seconds. Set the choke lever to the run position.

TO START A WARM ENGINE:

- 1  Slowly press the primer bulb 10 times or until the fuel fills the bulb.
- 2  Set the choke lever to the run position.
- 3  Hold down the throttle lock, and squeeze the throttle trigger.
- 4  Pull the starter grip and rope until the engine runs. Do not pull the starter grip more than 6 times.
or
 Using the ONE+ EASYSTART module:
Set the ONE+ EASYSTART module to , insert the module into the starter housing, and press the ONE+ EASYSTART power button for up to 4 seconds or until the engine starts.

TO STOP THE PRODUCT:

- 9  Push the switch to the off position.
NOTE: The switch is momentary, so it will always return to the on position.

