

# HD PREMIUM SHELVING UNIT

**1830H x 1955W x 610Dmm**

**ITEM NO: GOS140**

**Very Important:** Unpack the unit and confirm that you have all the parts listed. Assemble the unit on a solid, level surface. Avoid carpet. You will need the assistance of a second person during assembly.

**Safety tip:** For added safety and support we recommend you fix unit to a wall.

**You will need the following:** 2x Adjustable Spanner and rubber mallet.

**Please note:** When moving shelving unit lift using the uprights.



**WARNING**

SERIOUS INJURY OR  
DEATH CAN BE CAUSED BY  
TOPPLING FURNITURE

TO HELP PREVENT A TIP-OVER:

- We recommend you anchor this product to a wall or other suitable surface. • Check anchors regularly

FOR MORE INFORMATION SEARCH: [www.productsafety.gov.au](http://www.productsafety.gov.au)

POWDER COATED

**MATTE  
BLACK**


**800kg**  
PER SHELF



**SAFETY TIP:**


When assembling or installing  
this product wear protective  
gloves and eyewear.

## Parts List




NOT TO SCALE

## Step 1




Separate legs of first Upright 'A', unfold the attached braces (as per the above diagram) and fix the legs together using the provided Bolts and nuts 'F'. Please note: washers should be positioned either side of each brace. Repeat above steps for second upright.

## Step 2




Attach Beams 'B' to each Upright 'A' using the bottom keyholes and tap into place using a rubber mallet.



## Step 3




Repeat this step using two Beams 'B' for the top keyholes. Then attach the remaining beams at your desired heights, tapping them into place with a rubber mallet.

**Step 4**


Fasten Brackets 'C' to each Beam 'B' using the provided Bolts and nuts 'E' as per the diagram.

**Step 5**


Attach Braces 'D' to the top side of each Beam 'B' as shown above.

**Step 6**

Install Laminate shelves.

**Step 7**

Insert Rivets 'G' into holes at the ends of each Beam 'B' to secure them to the Upright 'A'.



**WARRANTY CONDITIONS:** Any claim under this warranty must be made within 1 year of the date of purchase of the product. To make a claim under this warranty, take the product (with proof of purchase) to any Bunnings store (for AUS customers see [www.bunnings.com.au](http://www.bunnings.com.au) and for NZ customers see [www.bunnings.co.nz](http://www.bunnings.co.nz) for store locations). Pinnacle Hardware bears reasonable, direct expenses of claiming under the warranty. You may submit details and proof of purchase to our support centre for consideration. The warranty covers manufacturer defects in materials, workmanship and finish under normal use. This warranty is provided in addition to other rights and remedies you may have under law: Our goods come with guarantees that cannot be excluded under the Australian consumer law or Consumer Guarantees Act 1993 (NZ). You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. This warranty excludes damage resulting from product misuse or product neglect, any modifications, additions or alterations to the product including the addition of extra shelves. Additions or modifications can compromise the structure and safety of the product. The warranty covers domestic use only and does not apply to commercial applications. This warranty is given by Pinnacle Hardware, ABN 87 614 496 196, 28 Hudson Court, Keysborough Vic 3173, 1800 349 776, Email: [support@pinnacle.net.au](mailto:support@pinnacle.net.au). Products sold in New Zealand are imported by Bunnings New Zealand. 'Pinnacle' is a trademark. © Pinnacle Hardware. Suitable for model number GOS140.