



1.0m Round Net Swing RNS03

CAUTION!

- WARNING! Fall danger!
- Only for ages 3+ with a 200kg maximum weight!
- For outdoor private domestic use only!
- The swing set must only be used under adult supervision.
- Assembly must be completed by an adult.
- Please keep these instructions for future use.
- To avoid injury, this product must not be modified.
- Retain any extra parts. They may come in handy in the future.

OPERATION INSTRUCTIONS

An adult should supervise play on the swing for the swing for children of all ages. Instruct children to: avoid swinging empty seats or swings; to not swing higher than hook or branches; only get off the swing after it has completely stopped and to hold the rope until both feet are planted firmly on the ground; to remove articles before playing on equipment that create hazards when they get tangled and caught (examples include: ponchos, scarves, and other loose fitting clothing, bike or other sports helmets); not to walk close to in front of, behind or between moving items.

MAINTENANCE

Before each use, check the rope, knots, nuts & bolts and all connections for evidence of deterioration, loosening excessive wear, fractures, breaks or sharp edges and replace as necessary. Take swing indoors when the temperature drops below 0 degrees Celsius.

WARNINGS

Curved platform swing supports up to four kid. On the premise of safety, you can sit, stand or lie on it. Maximum weight 200kg. To be under used under the direct supervision of an adult. This is a toy. Does not provide protection. Not suitable for children under three years.(For ages 3-12 years) Only for domestic use. **Do not sway above the hook. Don't play in the swing range.**

SAFETY ADVICE

- This swing is suitable for child/children over 3 years old with a maximum weight of 200kg.
- The swing set must only be used under adult supervision.
- This swing must never be used in public places, schools, campsites, hotels, public areas, etc.
- Your swing set should be set up on flat surface, 2 metres away from all other objects, poles or obstacles (walls, barriers, hedges, trees, washing lines, electrical cables etc.) that could cause injury to your child during use.
- The product must not be set up on hard surfaces (concrete, tarmac, etc.). Grass or softer surfaces are preferable.
- Ensure that persons keep distance of the swinging elements.
- There is a risk of strangulation by ropes.
- Assemble out of the reach of small children. The parts package includes small parts that can be easily inhaled or swallowed.
- Do not leave the packing within the reach of children. There is a risk of suffocation.
- Dispose of packaging responsibly.
- Monitor the surface where your swing set is installed; remove stones and all other objects that could injury to users if they fall.
- Complete frequent safety checks.
- Check and Re-tighten screw nuts when necessary.

Hanging Swing on your playground or swing set

- If the swing is placed next to a free swaying element(rope, rope ladder...) keep a minimum distance of 45 cm
 - If the swing is placed next to a stiff suspension element (double-swing, seesaw...)or next to a semi-flexible element (swing, trapeze) keep minimum distance of 45cm
 - Your play set or swing set must be installed on a horizontal and flat surface, to avoid the risk of tipping.
 - According to safety standards there should be a minimum distance of 35cm between the ground and the swing elements.
- This distance is very important to ensure safety.



WARNING:ONLY FOR DOMESTIC OUTDOOR USE

To guarantee safety. Please give special attention to the assembly,safety, and care instructions detailed in this document.