

18V CORDLESS

# MITRE SAW STAND

#### **INSTRUCTION MANUAL**

#### **SPECIFICATIONS**


Folded Size: 940 x 545 x 810mm Length: 940mm (Folded)

1950mm (Extended)


Height: 810mm (Folded) 920mm (Extended)

Loading Capacity: 150kg Weight: 9.65kg

ozito.com.au



#### STANDARD EQUIPMENT



Mitre Saw Stand




2 x Roller Arms, 2 x Mounting Bars, 2 x Extension Arms



4 x Fastening Knobs



4 x 60mm bolts, 4 x 35mm bolts, 4 x Washers, 4 x Spring Washers, 4 x Hex Nuts





IN ORDER TO MAKE A CLAIM UNDER THIS WARRANTY YOU MUST RETURN THE PRODUCT TO YOUR NEAREST BUNNINGS WAREHOUSE WITH YOUR BUNNINGS REGISTER RECEIPT. PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

### Australia 1800 069 486 New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. A CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

#### WARNING

The following actions will result in the warranty being void.

- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- · Failure to perform maintenance as set out within the instruction manual.
- If the tool is disassembled or tampered with in any way.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you at law.

Our goods come with guarantees that cannot be excluded at law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Generally you will be responsible for all costs associated with a claim under this warranty, however, where you have suffered any additional direct loss as a result of a defective product you may be able to claim such expenses by contacting our customer service helpline above.


#### **5 YEAR REPLACEMENT WARRANTY**

Your Product is guaranteed for a period of 60 months from the original date of purchase and is intended for DIY (Do It Yourself) use only. If a product is defective it will be replaced in accordance with the terms of this warranty. **Lithium Ion batteries and chargers are covered by a 36 month warranty** and are excluded from the warranty extension. Warranty excludes consumable parts.

## **KNOW YOUR PRODUCT**

#### **MITRE SAW STAND**

- 1. Mounting Bar
- 2. Fastening Slot
- 3. Mounting Bar Handle
- 4. Extension Arm Locking Pin
- 5. Roller
- 6. Material Support ShelfRed



- 7. Upper Leg Locking Pin
- 8. Stand Leg
- 9. Frame
- 10. Extension Arm Fastening Knob
- 11. Lower Leg Locking Pin
- 12. Extension Arm
- 13. Roller Arm
- 14. Roller Arm Fastening Knob

#### **ONLINE MANUAL**

Scan this QR Code with your mobile device to take you to the online manual.




## **SETUP & PREPARATION**


### 1. ASSEMBLY

#### **Unfolding The Stand**

- Lay the mitre saw stand on the floor with the folded legs facing up.
- 2. Depress the leg locking button and unfold the 2 upper legs until the locking button clicks into place.




- 3. Repeat the same procedure for the other 2 legs.
- 4. Lift the stand and flip it into the upright position.
- 5. Check that the stand is stable and all of the leg locking buttons have engaged properly.



#### Folding The Stand

1 pair of legs on the stand must fold in first for the stand to fold flat. The legs have not folded into place if the leg locking button does not pop into place. The legs should not swing about when the stand is picked up if the legs have locked into position.

- 1. Turn the mitre saw upside down on the floor with the legs sticking up.
- 2. Depress the leg locking buttons on the lower pair of legs and fold them in
- 3. Repeat the same procedure on the other pair of legs.






WARMING: THIS STAND IS INTENDED FOR USE WITH MITRE SAWS ONLY. DO NOT USE A STEP LADDER, STEPPING STOOL, STORAGE RACK, ETC.

OZITO WILL NOT BE LIABLE FOR DAMAGE OR INJURY CAUSED BY IMPROPER USE OF THIS UNIT.




#### Attaching The Extension Arms

1. Slide the extension arms into the frame.




**Note:** The locking pin on the extension arms should be facing inwards towards the centreline of the stand. You will need to depress this twice (once when the locking pin reaches the frame and again when it pops through the locating hole further in).


- 2. Continue sliding the extension arm into the frame until the desired length is reached.
- 3. Insert a fastening knob into the hole on the frame turn it clockwise to secure the extension arm in place.



 Insert a roller arm into the collar on the extension arm. The material support shelf should be facing inwards towards the centre of the stand.




5. Insert a fastening knob into the bracket and turn it clockwise to tighten the roller arm into place.



6. Repeat the same procedure with the opposite extension arm.

#### Attaching The Extension Arms

- Depress the mounting bar handles and hook the opposite end of the mount onto the frame of the stand.
- 2. Lower the handles onto the frame and release them to lock the mounting bar into place.



3. Repeat the same procedure with the other mounting bar.

### **OPERATION**

#### 2. ATTACHING A MITRE SAW





WARNING: ONLY USE A MITRE SAW THAT HAS 4 FIXING HOLES(1 IN EACH CORNER OF THE BASE) ON THIS STAND, AS OTHERWISE IT CANNOT BE PROPERLY SECURED. FAILURE TO FOLLOW THIS DIRECTION MAY RESULT IN DAMAGE TO PROPERTY AND/OR PERSONAL INJURY


#### Fastening The Mitre Saw


This unit comes with  $4 \times 35$ mm bolts and  $4 \times 60$ mm bolts. Either set may be used to fasten the mitre saw.

- 1. Adjust the mounting bars to roughly the width of the mitre saw base.
- Place the mitre saw on the mounting bars and line up the holes in the mitre saw base with the slots on the mounting bars.
- 3. Feed a bolt through the bottom of the mounting bar then through the base of the mitre saw.












WARMING! DURING OPERTAION AND BEFORE STARTING A NEW JOB, ENSURE THAT ALL SCREWS AND NUTS ARE TIGHTENED CORRECTLY AND SECURELY

#### 3. ADJUSTMENTS

#### Adjusting The Extension Arms

- Turn the fastening knob on the frame counter-clockwise to loosen it.
- 2. Pull the extension arm out to the desired length.




Note: The maximum extension length is reached when the arm locking pin clicks into place. To shorten the extension arm again, depress this pin and push the extension arm back into the frame.

3. Turn the fastening knob clockwise to tighten it and secure the extension arm into place.

#### Adjusting The Roller Height

- Turn the fastening knob on the collar of the extension arm counter-clockwise to loosen it.
- 2. Raise or lower the roller to the desired height.




3. Turn the fastening knob clockwise to tighten it and secure the roller into place.arm into place.

#### Using The Material Support Shelves

The mitre saw stand features material support shelves which allow repetitive cuts to be made quickly and accurately.

- Adjust the height of the roller arm so that the lip of the material support shelf is in line with the work surface of the mitre saw.
- 2. Adjust the extension arms to the desired cutting length.
- 3. Place the end of the workpiece against the material support shelf and commence the cut.



### **MAINTENANCE**



WARNING: BEFORE CLEANING OR CARRYING OUT ANY MAINTENANCE PROCEDURE, ENSURE THAT ANY MOUNTED POWER TOOL IS DISCONNECTED FROM THE POWER SUPPLY TO PREVENT ACCIDENTAL STARTING..

#### Cleaning

- Keep the ventilation slots of the tool clean at all times to ensure efficient operation.
- After each use, blow air through the tool housing to ensure it is free from all dust, dirt, etc. Build up of dust or dirt particles may cause the tool to overheat and shorten the life of the tool.
- If the housing of the tool requires cleaning, do not use solvents. Use of a cloth only is recommended.
- Never allow any liquid to get inside the tool, never immerse any part of the tool into liquid.

#### Storage

The Mitre Saw Stand can be easily folded for convenient storage and transportation. Detach the mitre saw before storage or transporting the mitre saw stand.

Follow the leg assembly instructions in reverse to fold up the Mitre Saw Stand.

Note: When transporting the Mitre Saw Stand in a vehicle, always tie it down to prevent movement and possible damage.

**Note:** Ozito Industries will not be responsible for any damage or injuries caused by repair of the tool by an unauthorised person or by mishandling.

### **DESCRIPTION OF SYMBOLS**

$\triangle$	Warning	<b>Q</b>	Wear eye, ear & breathing protection
<b>③</b>	Read instruction manual		

## **CARING FOR THE ENVIRONMENT**



Power tools that are no longer usable should not be disposed of with household waste but in an environmentally friendly way. Please recycle where facilities exist. Check with your local council authority for recycling advice.



Recycling packaging reduces the need for landfill and raw materials. Reuse of recycled material decreases pollution in the environment. Please recycle packaging where facilities exist. Check with your local council authority for recycling advice.

### **SPARE PARTS**

Spare parts can be ordered from the Special Orders Desk at your local Bunnings Warehouse.

For further information, or any parts not listed here, visit www.ozito.com.au or contact Ozito Customer Service:

Australia 1800 069 486 New Zealand 0508 069 486 E-mail: enquiries@ozito.com.au

## **GENERAL POWER TOOL SAFETY WARNINGS**



WARNING! Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

- 1) Work area safety
- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes
- c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- 2) Electrical safety
- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the powe tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock
- f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
- 31 Personal safety
- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
- h) Do not let familiarity gained from frequent use of tools allow you to become complacent and

second

- 4) Power tool use and care
- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired
- c) Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- h) Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
- 5) Battery tool use and care
- a) Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack
- b) Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- c) When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- d) Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- e) Do not use a battery pack or tool that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- f) Do not expose a battery pack or tool to fire or excessive temperature. Exposure to fire or temperature above 130 °C may cause explosion.
- g) Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions. Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire
- 61 Service
- a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintain
- b) Never service damaged battery packs. Service of battery packs should only be performed by the manufacturer or authorized service providers.

# 🕰 MITRE SAW STAND SAFETY WARNINGS



WARNING! The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

- Young children should be supervised to ensure that they do not play with the appliance
- Always ensure the mitre saw base is properly secured to the stand prior to operation.
- Always ensure the stand legs have been locked into place prior to operation.
- Take care when moving the stand especially when a mitre saw is mounted.
- Do not use the stand for any other purpose than what it is intended for. Do not use the stand as a stepping stool or ladder.
- Make sure all moving parts are free from interference
- Keep hands clear of all moving parts.
- Ensure the Mitre Saw Stand is set up on firm ground in a stable manner
- Use the Mitre Saw Stand in a dry place protected from the rain.
- Be aware of overbalancing. When a large piece is cut from one end of a job, the remaining

- piece may be heavy enough to over-balance the Mitre Saw Stand. Always ensure the workpiece is well supported.
- When transporting the Mitre Saw Stand in a vehicle, always tie it down to prevent movement and possible damage
- Check to make sure that all fixing screws and knobs are tight and all legs are locked into position before operation.
- The Mitre Saw Stand must be used only for its prescribed purpose. Any use other than those mentioned in these instructions will be considered a case of misuse.
- Ozito shall not be liable for any damage or injury resulting from such cases of misuse
- Ozito shall not be liable for any changes made to the Mitre Saw Stand nor for any damage resulting from such changes.
- Avoid using power tools for long periods of time without breaks. Vibration from tools can be transmitted into your hands and arms.
- Where possible, use clamps or a vice to hold the workpiece. It is safer than using your hand