


CORAL BAY LOUVRE PANEL GAZEBO

Assembly Instructions

Item Number: 0177358





Please carefully read the below warnings and instructions. Save the instructions for future reference.

- Before installing please contact your local council for semi permanent structure requirements.
- For permanent fixture contact your local council and use appropriate fixings.
- This gazebo is a Semi-Permanent structure. Damage caused by extreme weather conditions including heavy rain or high winds is not covered under warranty.
- Please carefully read all instructions before assembly and use.
- Please separate and identify all parts, ensuring that you have all parts listed.
- To avoid damage to your gazebo, it is recommended that you assemble it on a clean, protected surface.
- Washers must be used when indicated during the assembly process.
- Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.
- As an added precaution we strongly recommend you tighten any loose components after an initial period of use (around 3-6 months).
 For assured longevity and safe use of your gazebo, we recommend regular checking and tightening of any bolts.

IMPORTANT SAFETY INSTRUCTIONS


- The ground for erecting and anchoring the gazebo is required to be a level, solid and a safe surface.
- Beware of existing utilities underground.
- Keep away from any electrical installations and transportation devices.
- · Never climb, sit, or stand on the structure.


REF	PCE	PIECE	QTY	DIM
	А	Leg tube	3	
	A1	Leg tube	1	
	В	Roof frame	2	
	B1	Roof frame	2	
	С	Supporting frame	2	
	D	Louvre adjustment Component Centre	2	
	D1	Louvre Adjustment Component Edge	2	
	D2	Louvre Adjustment Component Edge	2	
	E	Roof frame	1	
	F	Shutter	60	<u>ئے</u>
	F1	Shutter	4	1
	G	Incline Stabiliser Brace	4	
	G1	Incline Stabiliser Brace	4	
	Н	Roof Edge Panel	2	
	J	Roof Edge Panel	1	


REF	PCE	PIECE	QTY	DIM
	J1	Cover plate	2	
	К	Inclined Bracket	2	
	K1	Corner Bracket	4	
	Г	Angled Connection Bracket	2	
	М	Leg base cover	4	
	N	Supporting Plate	2	
	N1	Supporting Plate	2	
	Р	Inclined connection plate	2	
	Q	Handle loop	4	
	Q1	Drainage Cover	2	
	Q2	Drainage Cover	2	
	R	Handle	1	
	S1	Washer	15	
	S2	Spacer Washer	3	


REF	PCE	PIECE	QTY	DIM
	AA	M6 x 18mm Bolt	86	
	BB	M6 x 30mm Bolt	23	
	СС	M6 x 35mm Bolt	8	
	DD	Hook	1	
	EE	ST4.2 x 12mm Screw	16	
	FF	M4 x 18mm Bolt	4	
	GG	Stake	8	
	НН	M6 x 39mm Bolt	32	
	JJ	Allen key	2	
	KK	Screw driver	1	
	LL	Spanner	1	


Connect the leg base covers (M) to the leg tubes (A &A1) using bolts (AA). Tighten securely using Allen key (JJ)







































Attach the handle loop (Q) to the protruding parts on the lower end of the centre louvre adjustment component (D), using bolts (FF). Tighten securely using screwdriver (KK).
















Before installing the shutter (F), use the handle (R) to rotate the louvre arms from position 1 to position 2 (as pictured above).






Insert the shutter(F) as shown, place the edge of the shutter(F) to the tip of the bayonet, then push shutter down until it clicks into place.




F X60

As shown, connect edge adjusting component D1 or D2 with roof frame(H), cover leaking hole(Q2), align the hole, and tighten the bolt(AA)



Your gazebo is now fully assembled. If your gazebo is located on a grassed surface, use the stakes (GG) to secure it in position (as pictured).





Please carefully read the below warnings and instructions. Save the instructions for future reference.

- Before installing please contact your local council for semi permanent structure requirements. For permanent fixture contact your local council and use appropriate fixings.
- This gazebo is a Semi-Permanent structure. Damage caused by extreme weather conditions including heavy rain or high winds is not covered under warranty. Please carefully read all instructions before assembly and use.

- Please separate and identify all parts, ensuring that you have all parts listed.

 To avoid damage to your gazebo, it is recommended that you assemble it on a clean, protected surface.
- Washers must be used when indicated during the assembly process.
- Loosely tighten the nuts and then securely tighten when all are in position. Be careful not to over tighten the nuts during assembly.

 As an added precaution we strongly recommend you tighten any loose components after an initial period of use (around 3-6 months). For assured longevity and safe use of your
- gazebo, we recommend regular checking and tightening of any bolts.

IMPORTANT SAFETY INSTRUCTIONS

- The ground for erecting and anchoring the gazebo is required to be a level, solid and a safe surface.
- Beware of existing utilities underground.

 Keep away from any electrical installations and transportation devices.
- Never climb, sit, or stand on the structure